ENGINEERING DESIGN GUIDE

B

YOUR ENHANCED GUIDE TO SORBOTHANE[®] SHOCK & VIBRATION SOLUTIONS

MADE IN USA

INTRODUCTION TO SORBOTHANE®



This design guide has been developed to assist engineers in a practical, hands-on approach to designing with Sorbothane[®]. This guide is advisory only. It is the responsibility of the user to verify the results. This guide does not take into account buckling or casting limitations of the material.

The data used in this manual is supported by empirical work. Sorbothane, Inc. offers additional technical support. You may contact support@sorbothane.com if you have questions. A program which parallels this calculation method can be found on the Sorbothane website (www.sorbothane.com).

Sorbothane is a polyether-based polyurethane. It is formulated for enhanced visco-elastic properties. Sorbothane is consistently effective over a wide temperature range (-20 to + 72 degrees Celsius).

Because Sorbothane is a non-Newtonian material stress is not proportional to strain and mechanical energy is "lost" by conversion to heat. The response of Sorbothane to a load is highly dependent on the rate of force application (frequency dependent responses).

Sorbothane is highly damped which makes it particularly desirable for difficult applications which require operation near or at resonant frequencies.

Sorbothane is available as custom-molded parts, select standard shapes and in sheet stock in a variety of thickness and sizes. Parts can be specified in durometers ranging from 30 to 80 on the Shore 00 scale.

The most effective static deflection for Sorbothane with a shape factor between 0.3 and 1.0 is in the range of 10-20%.

GLOSSARY OF TERMS

Vibration: A periodic motion around a position of equilibrium.

Random Vibration: Vibration whose magnitude is not specified for any given instant of time.

Shape Factor: The ratio of the loaded area to unloaded area of an isolator.

Static Deflection: The distance that a given mass compresses the isolator.

Percent Deflection: The fraction of static deflection to uncompressed thickness.

Frequency: The number of times the motion repeats itself per unit of time measured in Hertz (Hz).

Natural Frequency: The frequency of free vibration of a system.

Resonant Frequency: A frequency at which resonance exists.

Resonance: The frequency match between the natural frequency of the system and the external forced vibration frequency.

Damping: The dissipation of energy in an oscillating system.

Transmissibility: The ratio of the response amplitude of a system in steady state forced vibration to the excitation amplitude.

Isolation: A reduction in the capacity of a system to respond to an excitation.

Sorbothane

		-			
PROPERTY	DUROMETER (SHORE 00)			UNITS	NOTES
	30	50	70	- Critico	NOTED
Tensile Strength at Break	26	107	191	psi	ASTM D 412-06a
Elongation at Break	334	765	388	%	ASTM D 412-06a
Compression Set	10	3	2	%	ASTM D 395
Bulk Modulus	4.5	5.0	4.3	gPascal	
Density	83	84	85	lb/ft ³	ASTME D 792-13
Optimum Performance Temperature Range	-20° to +140°	-20° to +150°	-20° to +160°	°F	Reduced strength and damping up to 200°F. Increrased spring rate down to glass transition temperature.
Fungal Resistance	No Growth				ASTM G 22

Material Properties of Sorbothane®

Material Properties of Water Resistant Sorbothane®							
PROPERTY	DUROMETER (SHORE 00)			UNITS	NOTES		
	30	50	70	UNITS	NOTES		
Tensile Strength at Break	130	131	170	psi	ASTM D 412-06a		
Elongation at Break	342	219	154	%	ASTM D 412-06a		
Compression Set	10	2	3	%	ASTM D 395		
Bulk Modulus	4.25	3.99	4.14	gPascal			
Density	78.78	79.78	79.60	lb/ft ³	ASTME D 792-13		
Optimum Performance Temperature Range	-20° to +140°	-20° to +150°	-20° to +160°	°F	Reduced strength and damping up to 200°F. Increrased spring rate down to glass transition temperature.		
Fungal Resistance	No Growth				ASTM G 22		

Sorbothane® meets or exceeds the following compliance policies:

• ROHS • REACH • PROP 65 • Conflict Materials • Latex Free

SHAPE FACTOR

Shape Factor (SF) = $\frac{\text{Loaded Area}}{\text{Unloaded Area}}$

Rectangular Prism (SF) = $\frac{\text{Length x Width}}{2 \text{ x Thickness x (Length + Width)}}$

Square Prism (SF) = $\frac{\text{Length}}{4 \text{ x Thickness}}$

Disk (SF) = $\frac{\text{Diameter}}{4 \text{ x Thickness}}$

 $Ring (SF) = \frac{Outside Diameter}{4 \text{ x Thickness}} - \frac{Inside Diameter}{4 \text{ x Thickness}}$

Spherical Cap (SF) = $\frac{2 \times \text{Radius} - \text{Thickness}}{2 \times \text{Radius}}$

STATIC DEFLECTION

(Iterate until Assumed Percent Deflection agrees with calculated deflection within 3%)

Compressive Modulus = Cs Assumed Percent Deflection / / 100 • See Figure 4 on Pg. 7 for Cs • See Page 9 for Water-Resistant


Corrected Compressive Modulus = (Compressive Modulus) $x [1 + 2 \times SF^2]$

Static deflection $(\delta_{ST}) = \frac{\text{Load per Isolator x Thickness}}{\text{Corrected Compressive Modulus x Loaded Area}}$

Percent Deflection (% δ) = $\frac{\delta_{ST}}{\text{Thickness}} \times 100$


SYSTEM NATURAL FREQUENCY

(Iterate until assumed natural frequency agrees with calculated natural frequency within 3 Hertz.)



Sorbothane

SORBOTHANE®



Data obtained via Dynamic Testing (2018)






figure 3.





SORBOTHANE® ENGINEERING DESIGN GUIDE


SORBOTHANE®



WATER-RESISTANT SORBOTHANE®








WATER-RESISTANT SORBOTHANE®

0.1

50



100

150

Frequency (hz)

200

250

Data obtained via Dynamic Testing(2014)

Required Starting Information:

- 1. Weight (W) or Mass (m)
- 2. Velocity (V) or Drop Height (h)

For these examples the work will be in English units of:

- Acceleration of gravity (g) = 386.1 inches/second²
- Free fall drop height (h) in inches
- Dynamic deflection (δ) in inches
- Force (F) in pounds-force
- Kinetic Energy (KE) in pounds-force-inch
- Mass (m) in slugs
- Nominal spring rate* (k) in Pounds-force/inch
- Percent deflection (δ_{dyn} %) is unitless
- Velocity (V) in inches/second
- Part thickness (t) in line impact
- Static deflection (δ_{st}) in inches

Step 1.

Convert Weight in pounds-force to Mass:

$$m = \frac{W}{g}$$

Step 2. Calculate the Kinetic Energy (KE) for the impact:

For horizontal impacts only the mass is considered.

 $KE = 1/2 mV^2$

For vertical downward free fall drop impacts.

KE = Wh

Step 3. Calculate the Spring Rate for the trial part shape:

* Sorbothane has a non-linear spring rate. For purposes of simplification the rate is assumed linear based on its spring rate at 20% deflection.

There are three accepted methods to develop the nominal Spring Rate.

1. Use the Sorbothane Design Guide Program. This calculator is available at www.sorbothane.com. This is valid for parts with shape factor of 1.2 or less. Load the selected shape to 20% deflection. The program will calculate the static deflection ($\delta_{\rm st}$).

$$k = \frac{W}{\delta_{st}}$$

2. Use static deflection equations on page 2 to manually calculate the same values.

3. Load the given shape to a 20% deflection. Measure the static deflection $(\delta_{\rm st})$ and record the load (W) at this deflection

$$k = \frac{W}{\delta_{st}}$$

Step 4. Calculate the dynamic deflection:

The Spring Energy (SE) is expressed as

$$SE = 1/2 k \delta_{st}^2$$

Equate the Spring Energy to the Kinetic Energy.

KE = SE $KE = \frac{1}{2} k\delta^2$

Arrange terms and solve for dynamic deflection.

$$\delta_{dyn} = \sqrt{\frac{2 \times KE}{k}}$$

Step 5. Calculate the dynamic percent deflection:

$$\delta_{dyn}\% = \frac{\delta_{dyn}}{t} \times 100$$

For Shape Factors less than 1.2 and percent dynamic deflections less than 40% the expected fatigue life is considered to be in excess of one million cycle (indefinite).

For Shape Factors less than 1.2 and percent dynamic deflections between 40% and 60% the expected fatigue life is considered to be in excess of 1,000 cycles.


If the results achieved fail to achieve the desired performance then revise shape and/or durometer and repeat calculations.

The percent static deflection (continuous load without impact) must not exceed 20%.

There is no accepted methodology for higher shape factors or higher percent dynamic deflections.

Sorbothane

SAMPLE EQUATIONS



for 20% compression is 83 lbs and Static Deflection is 0.0375 in. 02 lbc

$$\% \ \delta = \frac{0.09 \text{ in}}{0.1875 \text{ in}} = 0.48 \Rightarrow 48\%^*$$

*Fatigue life is considered to be in excess of 1,000 cycles



2144 State Route 59, Kent, OH 44240 USA

Toll Free: 800.838.3906 USA Only | Phone: 330.678.9444 | Fax: 330.678.1303 | support@sorbothane.com | sorbothane.com